

2168 West Grove Parkway, Suite 300, Pleasant Grove, UT. 84062 USA Telephone: 801 229-2800 • Fax: 801 224-0355

IRX II WALL MOUNT - MODEL: IRX II-WALL

VANTAGE INSTALL GUIDES

Overview

The IRX II WALL mount option is designed to mount the IRX II to cabinets, walls, inside racks, etc. This unit is designed to hold one IRX II and allows the front and back side of the IRX II to be visible. The front and back are free of obstructions for easy access to wire connections and LED monitoring even when mounted. The wall mount has been constructed of high quality steel, which has been painted with a special black powder-coat paint that compliments the IRX II's own finish.

Specifications

DESCRIPTION	SPECIFICATION
Dimensions, HWD	6" x 8.6" x 2" 152mm x 219mm x 51mm
Weight	1.3 lbs / 590g
Finish	Black - powder coated

Installation

Installation of Vantage products should be performed or supervised by a Certified Vantage Installer. The wall mount has been designed so that the IRX II can be mounted with the cables exiting upward or downward.

- Decide on an appropriate location for the IRX II Wall mount before beginning.
- Use the wall mount as a template to mark the screw hole positions with a pencil.

- Install appropriate screws pan-head #6 screws.
 - Use plaster screw anchors if necessary to insure a secure hold.
- Secure the IRX II Wall mount device and tighten screws - do not over tighten.
- CAUTION: Only insert the IRX II with the top of the IRX II to the back of the wall mount holder as in Illustration One. The FEET on the bottom of the IRX II must face the front of the wall mount holder.
- The IRX II may be inserted either direction LEDs down or up as long as the FEET are to the front of the wall mount holder as illustrated.

Related Products

- IRX-II Install Sheet
- Rack Mount IRX II-RACK Install Sheet
- POWERED OPTO-ISOLATED EMITTER Install Sheet
- IR-LEARNERII Install Sheet
- **QUAD-SENSOR Install Sheet**

